



## INSTALLATION OF SOUNDSTOP® TACKABLE WALL PANELS

- 1) The Tack Board should be installed over 3/8" plywood or 1/2" gypsum wallboard. **Never install directly to studs.**
- 2) Panels should be acclimated to room temperature for a minimum of 24 hours before installation.
- 3) Panels should be matched for color orientation before applying adhesive.
- 4) If using a 1/8" trowel, apply solid across the full width of the panel using a good grade of construction adhesive. (**NOTE: Adhesive should be tested before beginning**)
- 5) If using adhesive from a tube. Make a figure 8" shaped pattern within 6" of each pattern.
- 6) At seams, use 3"x3" squares of 1/4" plywood with a dual head to pull the faces flush with each other. Leave the plywood squares in place until the adhesive has cured. **NOTE: Drive the nail through the plywood square first so the nail may be worked into the joint without going through the vinyl facing.**